


Home Assistant, ESPHome, BMP280 - temperature and pressure monitoring.

List:


- raspberry PI 3 or newer
- ESP32
- microSD card
- sensor BMP280 - temperature, pressure
- wires to connect ESP32 with BMP280
- cable to power ESP32 micro usb
- ethernet cable
- wifi dongle
- optional case for esp32 and sensor, I've made one - you can look here
https://github.com/karcio/stls/blob/main/esp32_sensor_bottom_v1.scad

ZDJECIE RPI3

ESP32



BMP280 sensor



ZDJECIE OBUDOWY

Prepare image HAOS:

- download HAOS for your rpi from
<https://github.com/home-assistant/operating-system/releases/tag/13.0>

```
https://github.com/home-assistant/operating-system/releases/download/13.0/haos_rpi2-13.0.img.xz
```

- unpack image

```
unxz haos_rpi2-13.0.img.xz
```

- insert sd card to your device and check how your machine recognize it - in mine case it is /dev/mmcblk0

```
sudo fdisk -l
```

- flash your sdcard

```
sudo dd if=Downloads/haos_rpi2-13.0.img of=/dev/mmcblk0 status=progress bs=1M
```

First run HA

- insert sd card to RPI
- connect Ethernet cable
- insert WIFI dongle to usb port
- connect power to RPI and wait while for HA to run
- on your router check your rpi Ip address
- in web browser insert rpi Ip address with port 8123, http://your_rpi_ip:8123
- first create account

Setup wifi connection on first run:

- go to Settings > System > select Network and then wifi tab
- in ip4 select automatic
- in WI-FI scan network to find your network and insert SSID and password. Save after that
- reboot rpi to set up wifi

Install Add-ons:

- go to : Settings > Add-ons
- click in add and install esphome and File editor
- esphome allows you to use esp32
- file editor allows you to edit config files and check syntax

HA config structure

- configuration.yml
- automation.yml
- secrets.yml

Connect BMP280 to ESP32

- BMP280 sensor has 6 pins but we use just 4: VCC, GRN, SCL, SDA
- connect pins as following:
 - BMP280 VCC → ESP32 3V
 - BMP280 GRN → ESP32 GRN
 - BMP280 SCL → ESP32 D22
 - BMP280 SDA → ESP32 D21

ZDJECIE PLYTKI Z PODLACZENIEM

Podłączenie esp32 do RPI

- podłącz esp32 za pomocą USB do RPI
- kliknij w ESPHome w zakładce
- kliknij dodaj nowe urządzenie

tak powinno wyglądać ustawienie:

```
esphome:
  name: esp32-01
  friendly_name: esp32-01

esp32:
  board: esp32dev
  framework:
    type: arduino
```

```
# Enable logging
logger:

# Enable Home Assistant API
api:
  encryption:
    key: "xxx"

ota:
  - platform: esphome
    password: "xxx"

wifi:
  ssid: !secret wifi_ssid
  password: !secret wifi_password

  # Enable fallback hotspot (captive portal) in case wifi connection fails
  ap:
    ssid: "Esp32-01 Fallback Hotspot"
    password: "xxx"

captive_portal:

i2c:
  sda: 21
  scl: 22
  scan: True

sensor:
  - platform: bmp280_i2c
    temperature:
      name: "bedroom temperature"
      oversampling: 16x
    pressure:
      name: "bedroom pressure"
    address: 0x76
    update_interval: 60s
```

a tak wygląda przykładowa automatyzacja, jak temperatura wzrośnie powyżej 25 stopni, lub spadnie poniżej 5 lub 0 - wysłany zostanie email z ostrzeżeniem. Chciałbym tutaj zaznaczyć, że poniższa automatyzacja dotyczy czujnika umieszczonego poza domem. Stąd te niskie wartości temperatury :)

```
alias: "Temperature"
description: low temperature level
trigger:
  - platform: state
    entity_id:
      - sensor.temperature
    to: null
    for:
      hours: 0
```

```
    minutes: 30
    seconds: 0
condition:
- condition: or
  conditions:
    - condition: numeric_state
      entity_id: sensor.temperature
      above: 25
    - condition: numeric_state
      entity_id: sensor.temperature
      below: 5
    - condition: numeric_state
      entity_id: sensor.temperature
      below: 0
action:
- data:
    message: "Temperature is: {{ states('sensor.temperature')}} C"
    title: "Warning: temperature is {{ states('sensor.temperature')}} C"
    action: notify.email_notification
mode: single
```

Dokładna dokumentacja jest tutaj: <https://www.home-assistant.io/installation/raspberrypi>

From:

<https://digitalhub.duckdns.org/wiki/> - **Wiki**

Permanent link:

<https://digitalhub.duckdns.org/wiki/doku.php?id=rpi&rev=1727635803>

Last update: **2024/09/29 18:50**

