


**Home Assistant, ESPHome, BMP280 - temperature and pressure monitoring.****List:**

- raspberry PI 3 or newer [raspberry pi](#) - cost about €43.09
- ESP32 [esp32](#) - cost about €3.5
- microSD card - cost about €10
- sensor BMP280 - temperature, pressure [bmp028](#) - cost about €1.5
- wires to connect ESP32 with BMP280
- cable to power ESP32 micro usb
- ethernet cable
- wifi dongle
- optional case for esp32 and sensor, I've made one - you can look here  
[https://github.com/karcio/stls/blob/main/esp32\\_sensor\\_bottom\\_v1.scad](https://github.com/karcio/stls/blob/main/esp32_sensor_bottom_v1.scad)


[Raspberry Pi 3](#)



[ESP32 controller](#)



BMP280 sensor



ESP32 custom case

**Prepare image HAOS:**

- download HAOS for your rpi from  
<https://github.com/home-assistant/operating-system/releases/tag/13.0>

```
https://github.com/home-assistant/operating-system/releases/download/13.0/haos_rpi2-13.0.img.xz
```

- unpack image

```
unxz haos_rpi2-13.0.img.xz
```

- insert sd card to your device and check how your machine recognize it - in mine case it is /dev/mmcblk0

```
sudo fdisk -l
```

- flash your sdcard

```
sudo dd if=Downloads/haos_rpi2-13.0.img of=/dev/mmcblk0 status=progress bs=1M
```

**First run HA**

- insert sd card to RPI
- connect Ethernet cable

- insert WIFI dongle to usb port
- connect power to RPI and wait while for HA to run
- on your router check your rpi Ip address
- in web browser insert rpi Ip address with port 8123, [http://your\\_rpi\\_ip:8123](http://your_rpi_ip:8123)
- first create account

**Setup wifi connection on first run:**

- go to Settings > System > select Network and then wifi tab
- in ip4 select automatic
- in WI-FI scan network to find your network and insert SSID and password. Save after that
- reboot rpi to set up wifi

**Install Add-ons:**

- go to : Settings > Add-ons
- click in add and install esphome and File editor
- esphome allows you to use esp32
- file editor allows you to edit config files and check syntax



**HA config structure**

- configuration.yaml
- automation.yaml
- secrets.yaml

**Connect BMP280 to ESP32**

- BMP280 sensor has 6 pins but we use just 4: VCC, GRN, SCL, SDA
- connect pins as following:
  - BMP280 VCC → ESP32 3V
  - BMP280 GRN → ESP32 GRN
  - BMP280 SCL → ESP32 D22
  - BMP280 SDA → ESP32 D21

ESP32 and BMP280 in case



**Connect esp32 to rpi for first initial flash**

- connect esp32 using usb cable to rpi do RPI
- open ESPHome tab
- click on add new device

this is sample of config file:

```
esphome:  
  name: esp32-01  
  friendly_name: esp32-01  
  
esp32:  
  board: esp32dev  
  framework:  
    type: arduino  
  
# Enable logging  
logger:  
  
# Enable Home Assistant API  
api:  
  encryption:  
    key: "xxx"  
  
ota:  
  - platform: esphome  
    password: "xxx"  
  
wifi:  
  ssid: !secret wifi_ssid  
  password: !secret wifi_password  
  
# Enable fallback hotspot (captive portal) in case wifi connection fails  
ap:  
  ssid: "Esp32-01 Fallback Hotspot"  
  password: "xxx"  
  
captive_portal:  
  
i2c:  
  sda: 21  
  scl: 22  
  scan: True  
  
sensor:  
  - platform: bmp280_i2c  
    temperature:  
      name: "bedroom temperature"  
      oversampling: 16x  
    pressure:
```

```
    name: "bedroom pressure"
    address: 0x76
    update_interval: 60s
```

This is how looks sample of automation config

```
alias: "Temperature"
description: low temperature level
trigger:
  - platform: state
    entity_id:
      - sensor.temperature
    to: null
    for:
      hours: 0
      minutes: 30
      seconds: 0
condition:
  - condition: or
    conditions:
      - condition: numeric_state
        entity_id: sensor.temperature
        above: 25
      - condition: numeric_state
        entity_id: sensor.temperature
        below: 5
      - condition: numeric_state
        entity_id: sensor.temperature
        below: 0
action:
  - data:
      message: "Temperature is: {{ states('sensor.temperature')}} C"
      title: "Warning: temperature is {{ states('sensor.temperature')}} C"
      action: notify.email_notification
mode: single
```

Whole documentation is here: <https://www.home-assistant.io/installation/raspberrypi>

From:  
<https://digitalhub.duckdns.org/wiki/> - **Wiki**

Permanent link:  
<https://digitalhub.duckdns.org/wiki/doku.php?id=rpi&rev=1727640017>

Last update: **2024/09/29 20:00**

